



## Instructions for Use

### Thermostrip® Dishwasher Labels

Surface Temperature Disinfection Indicator

**Thermostrip® DL** are self-adhering waterproof color-changing labels that measure the surface temperature of dishware in dish washing machines. Using Thermostrip® DL on a dish surface with each wash cycle will indicate that the proper sanitation temperature has been reached.

#### How to Use

- **Attach to the thickest clean dry dish**
- **Place labeled dish/utensil in dishwasher and run dishwasher**
- **Read label – Label will turn from silver to black when surface temperature reaches rated temperature**
- **Remove label and attach to dishwasher documentation**