



TEMPASURE

Proof that High Temperature Was Maintained

Quality Assurance for Low Temperature Sensitive Products

TYPE: **Tempasure** Indicator, Rectangular, Self-Adhesive
SIZE: 1.4"L x .07W x 0.2"H
EVENTS: 1
ACCURACY: +/-2°C
TEMPERATURE: in °F and °C,
PACKAGING: Packs of 10

Temperature

#	Description	Temperature	Size
D -20C	Descending	- 20°C	1.4"L x .7"W
D -10C	Descending	-10°C	1.4"L x .7"W
D - 5C	Descending	- 5°C	1.4"L x .7"W
D 0C	Descending	0°C	1.4"L x .7"W
D +2C	Descending	+2°C	1.4"L x .7"W
D +8C	Descending	+8°C	1.4"L x .7"W
D +10C	Descending	+10°C	1.4"L x .7"W

Instructions for Use

Allow sensor to stabilize at product temperature

Pull safety tab to activate sensor

Remove release liner and attach with self adhesive backing

A clear window indicates that the unit has not been exposed to critical low temperature

Indicator window shows red when exposed to a low temperature that is at or below its rating