

Tempasure

Quality Assurance for Products Sensitive to Low Temperature



- **Easy To Use and Read Self-Adhesive Pull Tab to Activate**
- **After Activation, Window Will Show Red at Temperature Below Indicated Rating**
- **Mechanical and Irreversible**
- **Sturdy and Small - Great For Storage And Transit**
- **Temperature Range:
-20°C to 10°C (-4°F to 50°F)**
- **Accurate to $\pm 2^{\circ}\text{C}$ ($\pm 3.6^{\circ}\text{F}$)**

#	Description	Size	Critical Temp
D-20C	Descending	1.4"L x 0.7"W x 0.2"H	-20°C
D-10C	Descending	1.4"L x 0.7"W x 0.2"H	-10°C
D-5C	Descending	1.4"L x 0.7"W x 0.2"H	-5°C
DOC	Descending	1.4"L x 0.7"W x 0.2"H	0°C
D+2C	Descending	1.4"L x 0.7"W x 0.2"H	+2°C
D+5C	Descending	1.4"L x 0.7"W x 0.2"H	+5°C
D+10C	Descending	1.4"L x 0.7"W x 0.2"H	+10°C

How to Use

1. **Allow sensor to stabilize at product temperature**
2. **Pull safety tab to activate sensor**
3. **Remove release liner and attach with self adhesive backing**
4. **A clear window indicates that the unit has not been exposed to critical low temperature**
5. **Indicator window shows red when exposed to a low temperature that is at or below its rating**

The Way It Works

SIMPLE ILLUSTRATION



Pull safety TAB to activate sensor. Attach with self-adhesive backing.



A clear window indicates the unit has not been exposed to critical low temperature.



Indicator clearly shows a red window when product has experienced temperatures below indicated rating.